
Resistor Color Code



What is resistor color code?

- visual method used to identify a resistor's size and precision
- makes use of 9 basic colors in form of colored rings call 'bands"
- can have 3 5 bands (3 and 4 are the standard)

Reading the Colors



Color Code (Standard 4 Band)

- 1st Band: 1st number
- 2nd Band: 2nd number
- > 3rd Band: multiplier (number of 0's after the 2nd number
- 4th Band: tolerance (5%, 10%, 20%)

Color Code Special Rules

- Black will never be used in the 1st band
- no 4th band means 20%
- Silver or Gold in 3^{rd} band means the resistor is a "fractional" resistor which means less than 10 (e.g. 4.5Ω , 3.1Ω , 6.7Ω , etc.)

Color Code Chart

BAND 1 1 ST DIGIT		BAND 2 2 ND DIGIT		BAND 3 MULTIPLIER		BAND 4 TOLERANCE	
Color	Digit	Color	Digit	Color	Multiplier	Color	Tolerance
Black	0	Black	0	Black	1	Silver	±10%
Brown	1	Brown	1	Brown	10	Gold	±5%
Red	2	Red	2	Red	100	NONE	±20%
Orange	3	Orange	3	Orange	1000		
Yellow	4	Yellow	4	Yellow	10,000		
Green	5	Green	5	Green	100,000		
Blue	6	Blue	6	Blue	1,000,000		
Violet	7	Violet	7	Silver	0.01		
Gray	8	Gray	8	Gold	0.1		
White	9	White	9				